



Noise

INTRODUCTION

In welding, cutting, and allied operations, noise may result from the process, the power source, or other equipment. Air carbon arc cutting and plasma arc cutting are examples of processes which are frequently noisy. Engine-driven generators may also be quite noisy. Excessive noise is a known health hazard.

DEFINITION

Scientifically, noise is composed of several frequencies and involves random changes in frequency or amplitude. Sound waves are produced when the air is mechanically disturbed. Sound is measured by its frequency (pitch-high or low) and intensity (loudness). Practically, noise is unwanted or unpleasant sound. It can get in the way of the sounds we would rather hear and often need to hear for safety reasons.

EFFECTS OF OVEREXPOSURE TO NOISE

- Loss of hearing that may be either full or partial and either temporary or permanent.
- Hearing loss may be a temporary threshold shift from which the ears may recover if removed from the noise source.

- The time required to develop permanent hearing loss depends on individual susceptibility, noise intensity, noise frequency and exposure duration.
- There is evidence that excessive noise can affect other bodily functions and behavior as well.

HOW TO PROTECT AGAINST NOISE

- Reduce the intensity of the source.
- Shield the source where practical.
- Use engineering control methods, such as room acoustics, to control noise.
- If engineering methods fail to reduce noise to acceptable levels, wear approved personal protective devices such as ear muffs or ear plugs, or both, as appropriate for the situation.
- Follow OSHA regulations which require a Hearing Conservation Program.
- If the noise level is questionable, have a safety specialist or industrial hygienist take measurements and make recommendations.
- Select tools and equipment to limit noise generation.

INFORMATION SOURCES

Occupational Safety and Health Administration (OSHA). Code of Federal Regulations, Title 29 Labor, Parts 1910 and 1926, available from the U.S. Government Printing Office, Washington, DC 20401; telephone: 800-321-6742; web site: www.osha.gov.

American Conference of Governmental Industrial Hygienists (ACGIH). *Threshold Limit Values for Chemical Substances and Physical Agents and Biological Exposure Indices*, available from ACGIH, 1330 Kemper Meadow Drive, Cincinnati, OH 45240-1634 (telephone: 513-742-2020; web site: www.acgih.org).

Mine Safety and Health Administration (MSHA). *Code of Federal Regulations* Title 30 Mineral Resources, Parts 1 to 199, available from the U.S. Government Printing Office, Washington, DC 20401; telephone: 202-693-9400; web site: www.msha.gov.

TLV is a registered trademark of the ACGIH.