



Selecting Gloves for Welding and Cutting

INTRODUCTION

Welding gloves can protect you from electric shock, flames, hot parts, sharp or flying metal, and arc rays. Proper gloves are the first line of defense against the hand hazards of welding and cutting. ANSI Standard Z49.1 (see Information Sources) requires that all welders and cutters wear protective gloves while working. Different processes may use different gloves. Here are some guidelines for selecting proper gloves for welding and cutting.

NATURE OF THE HAZARD

- Mechanical hazards that cause cuts, scrapes, tears, and punctures.
- Thermal hazards such as heat, flames, hot parts, arc rays, fire, molten metal, spatter, slag, and sparks.
- Electrical hazards due to gloves that are wet, torn, damaged, or have insulation failure.

GLOVE REQUIREMENTS

Gloves should be:

- Dry and moisture resistant.
- In good condition, no holes or tears.
- Flame resistant.
- Comfortable--proper fit and size.

- Electrically and thermally insulated to suit the process.
- Flexible--allow easy movement and full range of motion.
- Made with materials, seams, and edges that do not affect the health or safety of the user.
- Durable, tough, and long lasting.
- Cut, scrape, tear, and puncture resistant.

GLOVE MATERIALS

Many materials are available. Each has properties affecting its performance and use. Here is a list of typical materials and their useful characteristics:

- Cowhide—tough, durable, flame and heat resistant, with good electrical resistance when dry.
- Calfskin—better dexterity than cowhide but not as tough.
- Pigskin—flexible, oil resistant, quick drying.
- Rubber—moisture proof, electrical insulation.
- Treated Cotton—absorbent, lightweight, flexible.
- Aluminized—reflects heat radiation.
- Goatskin—light weight, comfortable, superior dexterity, durable.
- Deerskin—good touch sensitivity.

GLOVE DESIGN RECOMMENDATIONS

There are many different styles of gloves. Some protect only the fingers and palms. Others protect the entire hand. Still others protect the wrist and forearm as well. Some gloves have combinations of material, such as cowhide palms and pigskin backs. One pair of gloves may not be suitable for all processes. For example, gloves that are proper for low current Gas Tungsten Arc Welding (GTAW) (thin and flexible) would not be proper for high-current Air Carbon Arc Cutting (CAC-A) (insulated, tough, and durable).

Always use gloves as recommended by the manufacturer. Follow the provided instructions. Improper use may lead to injury if the gloves do not provide the needed protection. Check with your Safety Supervisor or Supplier. Be sure you have the right gloves for the job.

SUMMARY: HOW TO PICK THE RIGHT GLOVES FOR THE JOB

- Know the job.
- Know the process.
- Review the equipment.
- Determine the specific hazards.
- Match the gloves to the needs and hazards of the work.
- For help, ask your supervisor or supplier.

INFORMATION SOURCES

American National Standards Institute (ANSI). Safety in Welding, Cutting, and Allied Processes, Z49.1, available from American Welding Society, 8669 NW 36 Street, #130, Miami, Florida 33166; Web site: www.aws.org.

American Welding Society
8669 NW 36 Street, #130
Miami, Florida 33166
E-mail: info@aws.org
<http://www.aws.org>

AWS disclaims liability for any injury to persons or to property, or other damages of any nature whatsoever, whether special, indirect, consequential or compensatory, directly or indirectly resulting from the publication, use of, or reliance on this information. AWS also makes no guaranty or warranty as to the accuracy or completeness of any information published herein.

Occupational Safety and Health Administration (OSHA). Code of Federal Regulations, Title 29 Labor, Part 1910, available from the U.S. Government Printing Office, 732 North Capitol Street NW, Washington, DC 20401; Web site: www.osha.gov.

National Fire Protection Association (NFPA). *Standard for Fire Prevention during Welding, Cutting, and Other Hot Work*, NFPA 51B, available from National Fire Protection Association, 1 Batterymarch Park, Quincy, MA 02269-9101; Web site: www.nfpa.org.

NOTE: All the following European Standards are available from the British Standards Institution (BSI), 389 Chiswick High Road, London, England W4 4AL; Web site: www.bsi-global.com.

EN 388: *Protective Gloves against Mechanical Risks.*

EN 407: *Protective Gloves against Thermal Risks.*

EN 420: *Protective Gloves—General Requirements and Test Methods.*

EN 12477: *Protective Gloves for Welders.*

EN 60903: *Live Working - Gloves of Insulating Material.*

EN 702: *Protective Clothing—Protection against Heat and Flame.*

EN 1149-2: *Protective Clothing—Electrostatic Properties.*